


NOTES:

1)  - DENOTES SUB ASSEMBLY  
SEE DWG. 1001 THRU 1008

WEBER POINT  
FABRIC ASSEMBLY  
DWG. 1000 A